

LOCK REMOVAL

2. Use a small flat screwdriver to push this small rectangular button on side of the lock bezel

1. Insert key and rotate about 45°

4. Using the screwdriver push the diagonally opposite button and slowly remove the complete lock by pulling the key

3. Pull the engaged key and lock away from the table frame slightly

REPLACEMENT LOCK INSTALLATION

- 1. Rotate the key slightly in the replacement lock so the locking tab moves about 45 degrees and insert into the lock hole.
- 2. Push in firmly to engage the lock side clips.